


Apellation The connecting diagram of DSE-8610 controller for diesel Gen-set

GEN-SET MODEL : WCS1100S	FUSE	CIRCUIT BREAKER	TO REMOTE START CONNECTOR
ENGINE MODEL : KTA38-G5	POWER TERMINAL	PANEL LAMP SWITCH	TO ATS CONNECTOR
CONTROLLER MODEL: DSE-8610	LAMP		TO ENGINE CONNECTOR
VOLTAGE: 415V/3P			
FREQUENCY: 50Hz			
FULL LOAD CURRENT: 1419A			

Item	Name	Date	Item	Name	Date
Designer	3288	23/06/27	Checked	1353	
Proofread	1278		Approved	0746	
Drg. No	1000035970WCS1100S		Sheet	1/2	Edition 1.0





Apellation	The connecting diagram of DSE-8610 controller for diesel Gen-set			Item	Name	Date	Item	Name	Date
GEN-SET MODEL : WCS1100S		Designer	3288	23/06/27	Checked	1353			
ENGINE MODEL : KTA38-G5		Proofread	1278		Approved	0746			
CONTROLLER MODEL: DSE-8610		Drg. No	1000035970WCS1100S			Sheet	2/2	Edition	1.0
VOLTAGE: 415V/3P FREQUENCY: 50Hz FULL LOAD CURRENT: 1419A									



